

## Models: Northstar-C, C40-C, WarmMajic-II

## **MESH-HHT-C - Fire Screen**

This fire screen has been tested for use with specific Hearth & Home Technologies products. Check with your local building code agency before you begin installation to ensure compliance with local codes, including the need for permits and follow-up inspections. If you encounter any problems regarding code approvals, or if you need clarification of any of the instructions contained here, contact your Hearth & Home Technologies dealer. For the dealer nearest you, please visit www. hearthnhome.com

> **CAUTION!** Risk of Cuts, Abrasions or Flying Debris. Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

**Included in Kit:** (1) Fire screen, (2) handles and fasteners package **Tools Required**: Phillips Head screwdriver

- 1. Insert 8-32 screws through tabs from backside of screen. Using a Phillips head screwdriver, thread screws into handles and tighten.
- 2. Open both doors of fireplace.
- 3. Lift the screen up and over the top of the doors and place it down on the top door hinges.
- 4. Make sure the bottom brackets on the screen hook over and into the fireplace. See Figure 1.

